

61

MEMORY REFERENCE METHOD CHOICE MENU

- PLEASE CHOOSE THE MEMORY REFERENCE METHOD.
 - 1. UNCONDITIONAL REFERENCE TO DESIGNATED MEMORY
 - 2. REFERENCE TO THE REPRODUCING PLAYER
 - 3. CHOOSING BETWEEN 1 AND 2 EACH TIME

FIG. 4

<u>62</u>

REFERRED PLAYER CHOICE MENU

- OPLEASE DESIGNATE THE DVD PLAYER WHOSE MEMORY IS REFERRED.
- 1. PLAYER 1a (LIVING ROOM)
- 2. PLAYER 1b (PRIVATE ROOM)

.

RESUME TABLE 14







FIG. 6



21





OPLEASE CHOOSE THE RESTART POINT.

- 1. AFTER 10 MINUTES FROM THE BEGINNING
- 2. AFTER 16 MINUTES AND 20 SECONDS FROM THE BEGINNING
- 3. AFTER 18 MINUTES AND 15 SECONDS FROM THE BEGINNING

FIG. 10

<u>82</u>

